



DIAZOL XTRA (G225)

Main Characteristics

Type

Two Pack/Violet colour

Sensitizer Type

Powder

Solid content (unsensitized) %

40 %

Instruction for use

- Cut or tear the powder diazo sachet.
- Add the powder sensitizer to the bottle and add water until the bottle is approximately 2/3 full.
- Shake the bottle well until the contents have dissolved.
- Add sensitizer solution emulsion and stir well before use.
- Leave the emulsion to de-gas for 1 hr before use.

Preparing the Screen

- New screen should be abraded with Screenprep (SPR034) before use for optimum stencil durability.
- Degreasing the screen, use Degreaser Plus (P-6419)

Coating

Manual

- Apply one or two coats of Diazol Xtra, wet on wet, to the print side of screen.
- Apply one or two coats of this emulsion, wet on wet, to the squeegee side of screen.
- If a higher build of Diazol Xtra is required extra coats should be applied, wet on wet to the squeegee side.

Automatic

- When using an automatic coating machine, a simultaneous single coat on each side of the screen is recommended.
- If higher builds are required, extra coats should be applied to the squeegee side of the screen.

Drying

Put coated screen in hot air oven with squeegee side up. Do not exceed 40 °C.

Table of Exposure Guide

Light Source	Distance	Length of Exposure Time*
3000W Metal Halide	100 cm.	90-110 Seconds

* Using 120-34Y Polyester Screen Mesh.

Developing

Place the screen in washout booth and gently spray both sides, increase the spray pressure slightly. Continue developing until or parts of the image appear clean and sharp.

Spotting

Check for pinholes or blemishes. Spot out with a suitable filler use Screen Filler (22997)

Reclaiming the Screen

- Screenstrip Powder (SST002) thoroughly to both side of the stencil.
- Screenstrip Liquid (SST004) thoroughly to both side of the stencil.

Recommended inks

Solvent based ink and UV based ink.

Caution

Special safelight is not essential, but yellow or weak illumination is desirable.

CHAIYABOON BROTHERS CO., LTD.

26/17 M.3 Lumlukka Road, Lat Sawai, Lumlukka, Pathum Thani 12150 Thailand
 Tel : +662-533-2533, +662-994-5199
 Fax : +662-994-2449, +662-994-5180

SUPERB SUPPLIES SERVICE FOR SCREEN AND DIGITAL

www.chaiyaboon.com
 e-mail : sale_cb@cbg.in.th



Features

- Diazo sensitized emulsion.
- Highly resistant to strong solvents.
- Very easy to reclaim.
- The tack free surface of the emulsion makes it ideal for printing on to PVC.
- For high quality graphic printing.

Standard Packing

Emulsion : 1 Kg use with sensitizer code A7.5
 : 5 Kg use with sensitizer code B37.5

Safety and Handling

- Is free from any toxic, carcinogenic, mutagenic and reprotoxic chemicals.
- Does not have a flashpoint and is, therefore, exempt from the Highly Flammable Liquid Regulations.
- Should be stored away from children.
- Comprehensive information on *the Safety and Handling of Diazol Xtra* in Safety Data Sheet.

Storage

- Emulsion and sensitizer should be stored in temperature not over 25 °C.
- Unsensitized emulsion should be stored under similar conditions and can be stored for 24 months.
- Diazo sensitizer should be stored under similar conditions and can be stored for 12 months.
- Close the bottle tightly after every use.

Certified Standards

- G225 is made by Kulwong Co., Ltd. with ISO 9001/ISO 14001/BS OHSAS 18001 & TIS 18001 Certified by TUV NORD (Thailand) Ltd.

G225 2-2101